

7 / Ordering code

/ Actuators HSA Series

HSA 25	R4	BS 2	STD	MF (IEC 90 B14)	SCHEME 10	-	VU	C200	TS	FCP
1	2	3	4	5	6	7	8	9	10	11
1	Actuator size				HSA 10, HSA 25, HSA 50, HSA 100, HSA 150, HSA200					
2	Ratio				R1, R1.5, R2, R3, R4					
3	Ball screw				BS1, BS2, BS3, BS4					
4	Mounting attachments orientation				STD, RPT					
5	Input shaft / Main input				MF (IEC ____), S, R					
6	Kinematic scheme				SCHEME 10, SCHEME 20					
7	Additional output shaft and position				- (if not present) S 90, S 180, S 270, R 90, R 180, R 270					
8	Mounting position				U, D, VU, VD, HO					
9	Stroke				C_____					
10	Fixing accessories				- (if not present) TS, SP					
11	Limit sensors				- (if not present) FCP					